

### 000-028-529HD – Heavy Duty Urethane Rivet

(Sold in bags of 16)



**PRIOR TO ACCESSING PINSETTERS FOR INSTALLATION, ENSURE YOUR PINSETTERS ARE ISOLATED TO YOUR CENTRE or COMPANY'S SHUTDOWN & ISOLATION PROCEDURES.**

Traditionally the installation of Ball Cushion rivets has always been made far easier if the rivet is lubricated with a non-damaging substance like hand soap or dish soap. The 784-003-000 tool should also be used for maximum leverage.



Prior to installation of each rivet, simply smear some on the rivet's barb and in the case of the HD rivet, the area between the barb and flange as this is thicker now.



Twist and pull the tool to complete the process.