


Index No.	Part No.	Package / Order Reference	Description
1.	47-037474-009		Ball Guide Assembly - complete
2.	47-031309-001		Guide Tube
3.	47-034730-004		Plastic Tube (cover)
4.	47-035214-004		Spacer
5.	47-035211-000		Ball Rod Support Assembly
	5a. 47-035212-001		Pan Rod Support
	5b. 47-035213-002		Middle Holder - Ball Rod Support
6.	11-051078-000		Hex Head Cap Screw (M10 x 40 mm)
7.	11-051771-000		Lock Washer
8.	11-015045-000		Hex Head Cap Screw (M10 x 30 mm)
9.	47-035351-000		Protection Plate
10.	47-035311-004		Stiffening Plate - Ball Rod Support
11.	11-051019-000		Hex Head Cap Screw (M10 x 25 mm)
12.	11-051745-000		Locknut
13.	11-051035-001		Hex Head Cap Screw (M6 x 16 mm)
14.	11-053602-001		Lock Washer
15.	47-035371-004		Spacer

Ball Accelerator Guide



Ball Accelerator Guide