


Index

No.	Part No.	Description
1.	53-400844-000	Assembly, Rocker (includes Index Nos. 2 thru 17)
2.	53-400891-000	Rocker Washer - Neoprene
3.	53-400845-000	Rocker Roller
4.	53-400890-000	Rocker Wheel
5.	11-054824-000	Butto Head Screw
6.	53-400749-000	Rocker, Side Plate
7.	53-400753-000	Shock, Pin
8.	53-400847-000	Foam Rocker
9.	11-053101-001	Set Screw
10.	11-053624-001	Stop Ring
11.	11-440025-000	Bearing
12.	53-400811-000	Pin
13.	99-217171-009	Shock
14.	99-040151-004	Connector
15.	11-051706-001	Hex Nut
16.	53-400750-000	Rocker Side Plate, L.H.
17.	53-400751-000	Rocker Side Plate. R.H.
18.	11-051744-001	Locknut
19.	11-051010-001	Hex Head Cap Screw (M8 x 20 mm)
20.	11-051547-009	Socket Head Cap Screw (M8 x 50 mm)
21.	53-400883-000	Rocker Trim
22.	53-400851-000	Rocker Track
23.	53-400882-000	Rocker Trim Plate
24.	11-052940-000	Screw Socket Flat Head (M8 x 70 mm)

Surface 10-Pin Rocker



Surface 10-Pin Rocker