


Index No.	Part No.	Package / Order Reference	Description
1.	11-051569-000		Socket Head Screw (M10 x 120 mm)
2.	11-052028-001		Flat Washer (10 mm)
3.	11-051970-001		Locknut (10 mm)
4.	11-051045-001		Hex Head Cap Screw (10 mm x 30 mm)
5.	55-279458-000		Side Frame L.H. Front - Ball Accelerator
6.	55-279457-000		Side Frame L. H. Rear - Ball Accelerator
7.	55-279455-000		Side Frame R.H. Front - Ball Accelerator
8.	55-279456-000		Side Frame L.H. Rear - Ball Accelerator
9.	55-279461-000		Side Frame L.H. Front - Division Kickback
10.	55-279462-000		Side Frame L.H. Rear - Division Kickback
11.	55-279459-000		Side Frame R.H Front - Division Kickback
12.	55-279460-000		Side Frame R.H Rear - Division Kickback
13.	11-054829-000		Button Head Cap screw (M10 x 50 mm)
14.	11-052018-000		Flat Washer (M10)
15.	55-279306-000		Front Pit Board Assembly R.H.
	15a. 55-279306-C02		Top Pit Board R.H.
	15b. 55-279306-C01		Front Pit Board Plate R.H.
	15c. 55-279463-000		Long Strip
	15d. 11-051894-000		Torx Self Cntr Sink Head Wood Screw (M5 x 35 mm)
16.	55-279308-000		Rear Pit Board R.H.
	16a. 55-279308-C02		Rear Top Plate R.H,
	16b. 55-279308-C01		Rear Pit Board R.H.
	16c. 55-279308-C03		Rear Top Short Plate
	16d. 11-051897-000		Torx Self Cntr Sink Head Wood Screw (M4.5 x 20 mm)
17.	55-279305-009		Front Pit Board Assembly
17a.	55-279305-C02		Front Top Plate L.H,
17b.	55-279305-C01		Front Pit Board Plate
17c.	55-279463-000		Long Strip
17d.	11-051894-000		Torx Self Cntr Sink Head Wood Screw (M5 x 35 mm)
18.	55-279307-000		Rear Pit Board R.H.
	18a. 55-279307-C02		Rear Top Plate R.H.
	18b. 55-279307-C01		Rear Pit Board Plate L.H.
	18c. 55-279307-C03		Rear Top Plate L.H.
	18d. 11-051897-000		Torx Self Center Sink Head Wood Screw (M4.5 x 20 mm)

Pit Frames and Boards



Pit Frames and Boards