
Index			
No.	Part No.		Description
			•
1.	47-091690-002		Retaining Bow w/Flap
2.	47-091694-004		Square Spindle
3.	47-094099-004		Tension Spring
4.	47-093926-002		R.H Ejector Flap
5.	47-093927-002		L.H. Ejector Flap
6.	11-051769-001		Lockwasher (6 mm)
7.	11-051515-001		Socket Hd. Cap Screw (6 mm x 18 mm)
8.	11-051855-001		Retaining Ring (10 mm)
9.	47-090570-004		Shaft
10.	47-090572-004		Shaft
11.	47-090571-004	N.I. A	Shaft
12.	47-090565-002	N.A.	Bottom Housing
13. 14.	47-090560-004	N.A. N.A.	Bevel Wheel w/Cam Cam
15.	47-090557-004 11-052681-001	IN.A.	Rolled Pin (3 mm x 16 mm)
16.	47-090558-004		Cam Retainer
17.	47-090556-004		Retaining Lever
18.	47-094352-004		Tension Spring
19.	11-051768-001		Lockwasher (5 mm)
20.	11-051523-001		Socket Hd. Cap Screw (5 mm x 10 mm)
21.	47-090580-004		Tension Spring
22.	47-090577-004		R.H. Torsion Spring (Pin Nos. 2,4,6,8 & 10)
23.	47-090578-004		L.H. Torsion Spring (Pin Nos. 1,3,5,7 & 9)
24.	47-090562-003		Top Housing
25.	47-090559-004		Bevel Wheel
26.	47-091693-004		Clamping Lever
27.	47-091692-004		Pivoting Lever
28.	N.A.		Release Lever Pin (Pin Nos. 1,4,5 & 6)
29.	N.A.		Release Lever Pin (Pin Nos. 2,3,7,8,9 & 10)
30.	11-053478-001	N.A.	Speed Nut (8 mm)
24	47-861050-000	R.O.	Speed Nut (8 mm) Pkg. of 10
31. 32.	11-051514-001 11-052048-001		Socket Hd. Cap Screw (6 mm x 16 mm) Flat Washer (6.4 mm)
33.	11-052040-001		Locknut (6 mm)
34.	11-051524-001	N.A.	Socket Hd. Cap Screw (5 mm x 40 mm)
35.	11-051522-001	14.7 1.	Socket Hd. Cap Screw (5 mm x 16 mm)
36.	11-052042-001		Flat Washer (10 mm)
37.	11-050401-001	N.A.	Self-Tapping Screw (4 mm x 8 mm)
38.	11-051742-001		Locknut (5 mm)
39.	11-051509-001		Socket Hd. Cap Screw (6 mm x 12 mm)
40.	**N.A.		Retaining Bow without Flap
41.	47-093591-004		Release Lever Pin - two piece (Pin Nos. 2,3,7,8,9 & 10)
42.	47-093592-004		Release Lever Pin - two piece (Pin Nos. 1,4,5 & 6)
43.	**N.A.		Release Lever Pin - two piece (Pin Nos. 2,3,7,8,9 & 10)
44.	47-093590-004		Release Lever Pin - two piece (Pin Nos. 1,4,5 & 6)
45.	47-091725-004		Retaining Plate
46.	11-051741-001		Locknut (4 mm)
47.	11-052025-001		Flat Washer (4.3 mm)
48. 49.	11-052208-001		Sltd. Machine Hd. Screw (4 mm x 30 mm)
49. 50.	*N.A. *N.A.		Pin Station Assembly (Pin number 4) Pin Station Assembly (Pin Nos. 1, 5 & 6)
51.	*N.A.		Pin Station Assembly (Pin Nos. 1, 3 & 6)
52.	*N.A.		Pin Station Assembly (Pin Number 7)
53.	*N.A.		Pin Station Assembly (Pin Number 10)
			• · · · · · · · · · · · · · · · · · · ·

## N.A. = No Longer Available

**Pin Station Assembly** (Machine Series 55 to 333)

<sup>\*</sup> Use Universal Pin Station - pages 8J and 9J.\*\* Use appropriate Universal Pin Station.



Pin Station Assembly (Machine Series 55 to 333)