


No.	Index Part No.	Description
1.	14-100738-000	Side Cover (right-hand)
2.	14-100736-000	Rear Cover
3.	11-192028-000	Spacer(nylon)
4.	14-100742-002	Top Cover Assembly (right-hand)
5.	11-006127-000	Button Head Cap Screw (#10-32 x 1-1/4")
6.	14-100312-000	Hinge Nut Plate
7.	14-100373-000	Shim
8.	11-210008-000	Gas Spring (10lb. force)
9.	14-100740-002	Top Cover Assembly (left-hand)
10.	14-100737-000	Side Cover (left-hand)
11.	14-100358-000	Magnet Catch Plate
12.	11-190006-015	Flat Washer (#10)
13.	11-170006-015	Locknut (#10-32)
14.	11-170004-015	Locknut (#8-32)
15.	11-210007-000	Gas Spring Bracket
16.	14-100922-000	Envoy Logo
17.	53-860648-000	Brunswick Logo
18.	11-532004-009	External Retaining Ring
19.	11-112201-000	Latch
20.	11-054301-015	Cover Pin (front)
21.	14-100875-001	Cover Pin (rear)
22.	14-100875-002	Cover Pin (middle)
23.	14-100876-000	Cover Pin (guide)
24.	11-199002-015	Lockwasher (#8)
25.	11-006063-009	Buton Head Cap Screw (#8-32 x 1/2")

Hood System



Hood System