


Index No.	Part No.	Description
1.	14-100162-000	Cord Kill Switch Assembly
2.	11-616031-000	Switch
3.	11-006007-000	Button Head Cap Screw (#4-40 x 5/8")
4.	11-170000-015	Nut (#4-40)
5.	14-100161-000	Switch Bracket
6.	14-100267-000	Cord Kill Stud Assembly
7.	14-100159-000	Cord Kill Switch
8.	11-530031-015	Retaining Ring (external)
9.	11-581012-000	Spring
10.	14-100160-000	Cord Kill Switch Sleeve
11.	14-100209-000	Isolation Transformer
12.	14-100154-115	Electrical Control Enclosure Assembly (115VAC)
	14-100154-230	Electrical Control Enclosure Assembly (230VAC)
13.	11-021022-001	Pan Head C.R. Screw w/Lockwasher (#6-32 x 3/8")
14.	14-100498-000	Emergency Stop Switch Assembly
15.	14-100085-000	Power Switch to Circuit Breaker Wire Assembly
16.	14-100418-000	Motor Control PCB Assembly
17.	14-100466-400	Controller PCB Assembly
18.	14-100414-000	Injector Drive PCB Assembly
19.	14-100285-115	Regenerative Drive (115V)
	14-100285-230	Regenerative Drive (230V)
20.	11-190004-015	Flat Washer (#8)
21.	11-176005-015	Hex Nut w/Lockwasher (#6-32)
22.	11-672524-115	Relay General Purpose (100/120 AC)
	11-672524-230	Relay General Purpose (200/240 AC)
23.	14-100157-000	Power Supply
24.	14-100146-000	Cautions and Warnings Decal
25.	14-100240-000	Input Power to Terminal Block Cable Assembly
26.	14-100247-000	Power Switch to Circuit Breaker Cable Assembly
27.	14-100245-000	Power Motor PCB to Controller Cable Assembly
28.	14-100264-000	Power Supply to Motor PCB Cable Assembly
29.	11-616030-115	Circuit Breaker (16A, 32VDC, 250VAC)
	11-616030-230	Circuit Breaker (10A, 230 VAC)
30.	11-616029-115	Hi-Inrush Switch (115V)
	11-616029-230	Hi-Inrush Switch (230V)
31.	11-900717-000	"Emergency Stop" Decal

Electrical Enclosure



Electrical Enclosure