


| <b>Index No.</b> | <b>Part No.</b>   | <b>Package / Order Reference</b> | <b>Description</b>               |
|------------------|-------------------|----------------------------------|----------------------------------|
| 1.               | 47-035555-009     |                                  | Ball Door Assembly w/Arm, L.H.   |
| 2.               | 47-031054-002     |                                  | Ball Door Assembly               |
|                  | 2a. 47-031054-C01 |                                  | Ball Door - only                 |
|                  | 2b. 11-054463-000 |                                  | Self Tapping Screw (KB30 x 7 mm) |
| 3.               | 11-051793-000     |                                  | Split Pin                        |
| 4.               | 11-051743-000     |                                  | (M6 ) Locknut                    |
| 5.               | 11-051067-000     |                                  | Hex Head Cap Screw (M8 x 35 mm)  |
| 6.               | 11-430046-000     |                                  | Bearing                          |
| 7.               | 11-051743-000     |                                  | Locknut                          |
| 8.               | 47-031822-004     |                                  | Lever                            |
| 9.               | 47-031058-001     |                                  | Arm w/Bushings                   |
|                  | 9a. 47-035099-001 |                                  | Arm                              |
|                  | 9b. 47-034842-004 |                                  | Bushing                          |
| 10.              | 47-030276-004     |                                  | Tension Spring                   |
| 11.              | 11-053101-001     |                                  | Set Screw                        |
| 12.              | 11-053622-000     |                                  | Stop Ring                        |
| 13.              | 47-035238-004     |                                  | Ball Door Arm, Shaft             |
| 14.              | 11-053477-001     |                                  | Speed Nut                        |
| 15.              | 47-034767-004     |                                  | Spring                           |
| 16.              | 47-031056-003     |                                  | Ball Door Key, L.H.              |
| 17.              | 47-031091-004     |                                  | Shaft                            |
| 18.              | 11-051018-000     |                                  | Hex Head Cap Screw (M6 x 20 mm)  |

## Ball Door/Lock Assembly, Left Hand (Subway)



**Ball Door/Lock Assembly, Left Hand (Subway)**